

Steps to apply the Shaft Lean Alignment Aid

- Make sure the grip is centered on the shaft.
 - Measure the length of the shaft from the grip to the head of the club
 - Cut the long decal on the black and red end 1 inch shorter than the length of the shaft
 - Clean the shaft and wipe it down with alcohol
-

- Locate and mark the top center of the grip where the shaft starts with one of the small red line decals. -A



- Locate and mark the top center of the shaft where the hosse of the club is connected, use the small red line decal -B
(Make sure the club head is square to impact)



- Mix 1 drop of dish washing liquid into a cup of warm water. Use your finger to "lightly" apply the soapy water to the top center of the shaft. Starting at 1/2 inch, just below the grip. This is where the decal will be attached to the shaft. Be careful not to wipe off the soapy water.

- Remove 1 inch of the white backing from the end where the color lines are. Align the center red line on the decal with the red line on the grip. Attach 1/4 inch of the decal to the shaft. Use your fingertip to hold it in place. Pull the backing off the decal completely. Gently align the center red line on the decal down the center of the shaft. Use the red line decal as a center guide. -C



Tip: Place the end of the grip against the wall and place the head of the club against your chest to hold the shaft firmly in place to apply the decal.

- While holding the decal in place with your finger tip, look down the shaft to ensure the red line is down the center of the shaft. If it's not centered, slowly lift the decal to reposition it. You can also gently pull the decal on either side to align it to the center of the shaft. -D



- Once the decal is centered on the shaft press the decal from the center red line out to the edge. (90 degrees across the complete shaft length on both sides) This will prevent wrinkles on the edges.



- Place the red and white decal on the end of the shaft. Align the red line to match the red line on the decal down the shaft. Once centered press from the center out to the edge. Wrap one side completely around, then wrap the other side. They will overlap each other. - E
- Remove the two small red line markers from the club.-A& B



Tip: Hold the club at address position lean the grip end of the club (L) or (R) for your Shaft Lean alignment position. Without moving your head, look down at the colored lines on the decal to see which angle line is straight in your view.

- Once you have chosen the angle you prefer, take the small decal with the red line on it and place it over the top of the Shaft Lean alignment angled line you have chosen. Align the small decal so the narrow end of the decal is on the center red dot and the other end of the red line aligns with your preferred Shaft Lean alignment colored line. Press the decal into place from the center out to the edges. Take a moment to ensure that all edges are pressed firmly onto the shaft. -F



Thank you for your purchase of the **Shaft Lean Alignment Aid**

Now go enjoy the game and have some fun!



Straightline Golf LLC